



R 4, 5, 32, 3, 1, 10, 9, 12, 11, 14, 15, 16, 13, 18, 19, 20, 31, 21, 22,
 C 2, 3, 4, 1, 5, 14, 6, 7, 40, 9, 8, 12, 37, 13, 35, 10, 15, 17, 19, 25, 26, 16, 36, 41, 11, 21, 22,
 L 1, 2, 5, 7, 3, 4, 6, 8, 9, 10, 13, 15, 11, 12, 14, 16, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 34, 62, 63, 30, 31,



PREPINAČE P1, P2

NAPĚTÍ	SPOJENÉ DOTEKY P4
120V (110V) ≈	a-b, d-e,
150V (125V) ≈	a-c, f-e,
220V (210V) ≈	b-c, a-f,
240V (220V) ≈	a-d, —

ROZSAH

ROZSAH	SPOJENÉ DOTEKY P1	SPOJENÉ DOTEKY P2
KV1	7-8, 9-10,	8-7, 9-10-12,
KV2	7-8, 11-12, 13-14, 15-16,	7-8, 9-10-12, 13-14, 17-18,
SV	13-14, 17-18, 19-20, 21-22,	13-14, 22-23, 7-8,
DV	19-20,	13-14,

PATICE ELEKTRONEK

